



Firmware 08 03 00 Update Instructions for C, E, G and J models

How-to guideline for the installation of firmware

Here is how – if the relevant **Cdy_8_3_0.zip** file has been downloaded or sent to you via e-mail:

OPTION 1:

1. Unzip / Extract the **cdy_8_3_0.zip** folder to your PC / laptop
2. Copy **ONLY** the applicable .fw file labelled 'cdy_1200_8_3_0.fw' onto a clean / formatted standard size SD memory card not larger than 32GB (this .fw files are located inside the new cdy_8_3_0 folder).

File cdy_1200_8_3_0.fw is for C, E, G & J Series cameras

3. Insert the SD card back into the camera trap
4. (For **C / E / G & J Series cameras**) - Press MODE until COMMANDS is displayed. Press MORE until LOAD F/W is displayed. Then press UP or DOWN arrow to proceed.

OPTION 2:

1. DO NOT Unzip / Extract the **cdy_8_3_0.zip** folder to your PC / laptop
2. Copy the entire cdy_8_3_0.zip folder onto a clean / formatted standard size SD memory card not larger than 32GB.
3. Insert the SD card back into the camera trap
4. (For **C / E / G & J Series cameras**) - Press MODE until COMMANDS is displayed. Press MORE until LOAD F/W is displayed. Then press UP or DOWN arrow to proceed.

PLEASE NOTE - battery level must be 50% or greater for firmware to load (please do not try to open the .fw files on your computer as they will not be able to read them)

If you have questions on this, or the products themselves, or if you need other assistance for want to place an order, please feel free to contact us.

Kind Regards

CAMERA TRAPS cc

Web: www.cameratrap.co.za
E-mail: info@cameratrap.co.za
LEVEL 4 B-BBEE CONTRIBUTOR